

MINOLTA PROGRAM/MAXXUM FLASH 2500 (D)

Specifications

Type	Auto-electronic flash			
Compatible cameras*	Minolta Maxxum 9, 9Ti, 7, 5, 4, 3, and si-, xi-, and i-series AF SLRs. DiMAGE 5, DiMAGE 7 series digital cameras, DiMAGE A1, and the DiMAGE Z1.			
Flash mount	Minolta dedicated shoe mount with automatic lock			
Guide number	82 (in feet at ISO 100) / 25 (in meters at ISO 100)			
Flash coverage	28mm angle of view			
Bounce flash	Flash head can be tilted between 0 - 90° (click-stop at 60°).			
AF illuminator*	Automatically activates in low light and low-contrast situations. Range: Approximately 3.3 – 16.4 ft. (1 – 5 m) with 50mm lens			
Flash metering*	TTL metering. Pre-flash used depending on the camera.			
Ratio flash*	2:1 when connected with Program/Maxxum Flash 5600HS (D), 5400xi, 5400HS, or 5200i. The lighting ratio set with the connected flash unit.			
Batteries	Four AA batteries (alkaline, Ni-MH, or lithium)			
Recycling time and battery performance	Approximate recycling time and number of flashes that can be fired with fresh batteries:			
		<u>Alkaline</u>	<u>Ni-MH</u>	<u>Lithium</u>
	Recycling time:	0.2 – 6 seconds	0.2 – 5 seconds	0.2 – 6 seconds
	Number of flashes:	200 – 4,000	200 – 4,000	500 – 10,000
Dimensions (WxHxD)	2.56 x 4.53 x 2.72 inches (65 x 115 x 69mm)			
Weight	6.7 oz. (190 g) without batteries			
Standard accessories	Flash case			
Optional accessories*	Off-Camera Shoe OS-1100, Flash-to-flash Cable CD, Off-Camera Cable OC-1100, Triple Connector TC-1000, Extension Cable EX			

*Compatibility with functions and accessories varies with the camera and lens in use.

Specifications and accessories are subject to change without notice.

#